



# Installation Instructions

## Rear View Camera

v1.2 (24.11.2021)

## Contents

|           |   |           |
|-----------|---|-----------|
| <b>1</b>  | <b>Liability Exclusion</b>  | <b>3</b>  |
| <b>2</b>  | <b>Copyright</b>  | <b>4</b>  |
| <b>3</b>  | <b>General notes</b>  | <b>4</b>  |
| <b>4</b>  | <b>Safety Instructions</b>  | <b>5</b>  |
| <b>5</b>  | <b>Requirements for the intended use</b>                          | <b>5</b>  |
| <b>6</b>  | <b>How to connect a cable to another</b>                          | <b>6</b>  |
| <b>7</b>  | <b>Note Cable Inscription/Color</b>                               | <b>7</b>  |
| <b>8</b>  | <b>Assembly Instructions</b>                                      | <b>8</b>  |
| <b>9</b>  | <b>Assembly Note</b>  | <b>9</b>  |
| <b>10</b> | <b>Disassembly tailgate covering</b>                              | <b>10</b> |
| <b>11</b> | <b>Assembly camera</b>  | <b>12</b> |
| <b>12</b> | <b>Disassembly A-column covering / sill trim passenger's side</b> | <b>13</b> |
| <b>13</b> | <b>Cable routing trunk</b>  | <b>15</b> |
| <b>14</b> | <b>Cable routing main unit</b>                                    | <b>16</b> |
| <b>15</b> | <b>Disassembly main unit</b>                                      | <b>17</b> |
| <b>16</b> | <b>Connection cable set</b>                                       | <b>18</b> |
| <b>17</b> | <b>Alternativ Connection CAN High + Can Low</b>                   | <b>20</b> |
| <b>18</b> | <b>Coding with Coding Interface</b>                               | <b>21</b> |
| <b>19</b> | <b>Coding Interface</b>   | <b>21</b> |
| <b>20</b> | <b>Bus rest</b>   | <b>21</b> |
| <b>21</b> | <b>Anschluss/Fehlersuche Kabelsatz</b>                            | <b>22</b> |

## 8 Assembly Instructions

The following illustration shows the cable routing as well as the position of the individual components.




Figure 3: Vehicle overview

- 1 Rear view camera
- 2 Ground
- 3 Connection cable set

Please be aware that this overview is only for **illustration purposes**. Always lay the cable set in the **most convenient and shortest way** possible. For a detailed description of the cable routing, please refer to the relevant sections of the following manual.